

HOW TO INSTALL SNAPS

No Snap Custom Fit Cover

Extra male & female snaps are included. We recommend that you practice on the included sample fabric prior to making alterations to your cover.

Items Needed:

- 1.) Snapping Tool
- 2.) Male Studs
- 3.) Female Studs
- 4.) China Markers/Felt Tip Markers
- 5.) Sample Fabric

Step 1. Mark the area where you want the snaps to be installed with the included china markers. It is preferable to mark both sides of the cover with a line.

Step 2. 1. Place the male stud inside the rubber holder of the snap tool (Fig. 1).
2. Attach the female stud to the non-rubber side of the snap tool (Fig. 2)



Fig. 1

Fig. 2

Step 3. Align the male stud with the line marked in Step 1 and firmly press the tool until the snaps are engaged (Fig. 3).



Fig. 3